

G01/G02 Personal/Pet GPS Tracker

User Manual

- 1. Insert 2G GSM SIM Card (Nano Size) with GPRS data service activated. Please charge device 3 hours before using.**



2. Button & Indicator

- Long pressing button to power on device; Indicator will show off after read SIM card;
- Long pressing 3s until indicator flash one time can send SOS alarm to **center number**;
- Long pressing more than 6s until indicator off to power off device.

3. Command List

Default password 123456, use mobile phone to send SMS as below to tracker's phone number, don't type "+" "space". Each command must reply "configure OK" means succeed. Check APN website <http://bigfun.tripod.co.uk/>

| Function | Format | SMS Command |
|--|-------------|--|
| Step 1 Set APN | Format | apn123456+space+localApn+space+ApnName +space+ApnPassword |
| | Eg.send SMS | apn123456 tim.br tim tim |
| Device Default GPS mode last 12 hours | | wkmd123456+space+2 |
| Open LBS mode last 65hours | | wkmd123456+space+1 |
| Open Real time GPS mode last 6 hours | | wkmd123456+space+0 |
| Set center number to receive alarm | | centernum123456+space+user phone number |
| Cancel center number | | centernum123456 |
| Check device parameter status | | check123456 |
| Voice listen mode (Personal use) | | monitor123456 |
| Recover tracker Mode | | tracker123456 |
| Activate Low battery alarm | | lowbat123456+space+1 |
| Cancel Low battery | | lowbat123456+space+0 |
| Initialize factory setup (No need use) | | begin123456 |
| Set IP Port (No need use) | | adminip123456+space+IP+space+port |

4. GPS Tracking System www.secumore1818.com

Website: www.secumore1818.com

Default IMEI as ID Number user name, password: 123456.

If failed, please contact supplier to register IMEI.

Attentions before login GPS Software:

- Make sure you configured APN SMS as command list
- For first using put device outdoor to get acquire signal to show location on map (icon on map will show colored icon)
- Gray color means device never get GPS signal/SIM card has no GPRS data service/wrong configured APN (won't show correct location)
- GPS only update location at every 10mins(accuracy 10m). If device indoor, map icon will show "LBS" status (accuracy100-1000meters)

If need Accurate location, move to outdoor; Indoor is not accurate locating.